



Master Light Toolbox User's Guide



www.ExcaliburElectronics.com

Model No.:H638S-WC-CS

Congratulations on your purchase of The Weather Channel® Master Light Toolbox from Excalibur Electronics. It combines a bright LED flashlight with a utility toolbox. It also features a powerful mounting magnet, and with the EZ Crank, the batteries never need replaced!


The Weather Channel® Master Light Toolbox is easy to use. Be sure to keep this User's Manual for your reference

Your set includes :

- 9 Screwdriver heads
- 4 Precision screwdrivers
- 8 Socket heads
- 1 Hexagonal connector
- 1 EZ Crank handle and multitool
- 1 Tool extension
- 1 Toolbox

Features

- Flashlight with alert
- No batteries needed
- Adjustable brightness
- 25-piece toolkit with box
- Powerful mounting magnet



Charging the Flashlight

Make sure that the Master Light is off before charging. Insert the EZ Crank handle into the Winding port located at the base of the Master Light Toolbox. Rotate the EZ Crank handle clockwise for three minutes to fully charge. After a full charge you will have approximately 180 minutes of bright light on the "Low" setting, or 60 minutes on "High".

Note: Battery life may vary.

Operating the Flashlight

Push the Power Button on the door to turn the flashlight on. To increase the brightness of the flashlight, push the power again. Press this button a third time to activate the flashing alert light. Press it one more time to turn the flashlight off.

The Weather Channel® Master Light Toolbox features a pivoting lamp head. To use this feature, press the Lamp release buttons on either side of the LED lamp in, and pull up on the lamp head. With the lamp head fully extended, you can pivot the light 180 degrees.

Using the Mounting Magnet

The Mounting magnet at the bottom of the unit can be used to attach the toolbox to almost any metal surface for convenient use.

Using the Multitool

The EZ Crank handle doubles as a multitool that connects to your sockets and screwdriver heads. Insert the screwdriver heads directly into the end of the multitool. To use the sockets, insert the hexagonal connector into the end of the multitool, then connect your socket. Use the Tool extension with sockets and screwdriver heads to make work easier!

Safety and Care

- Avoid rough handling such as bumping or dropping.
- Clean using only a slightly damp cloth.
- Do not submerge the lantern in water or other liquids.
- For best results, use between 39° F and 100° F (4° C - 38° C).
- LED bulbs are not replaceable. Do not attempt to open light housing. Doing so could damage the unit.
- Do not look directly into the light. This may damage eyes.

90-DAY LIMITED WARRANTY

EXCALIBUR ELECTRONICS, INC., warrants to the original consumer that its products are free from any electrical or mechanical defects for a period of 90 DAYS from the date of purchase. If any such defect is discovered within the warranty period, EXCALIBUR ELECTRONICS, INC., will repair or replace the unit free of charge upon receipt of the unit, shipped postage prepaid and insured to the factory address below.

The warranty covers normal consumer use and does not cover damage that occurs in shipment or failure that results from alterations, accident, misuse, abuse, neglect, wear and tear, inadequate maintenance, commercial use, or unreasonable use of the unit. This warranty does not cover cost of repairs made or attempted outside of the factory.

Any applicable implied warranties, including warranties of merchantability and fitness, are hereby limited to 90 DAYS from the date of purchase. Consequential or incidental damages resulting from a breach of any applicable express or implied warranties are hereby excluded. Some states do not allow limitations on the duration of LIMITED 90-DAY WARRANTY implied warranties and do not allow exclusion of incidental or consequential damages, so the above limitations and exclusions in these instances may not apply. The only authorized service center in the United States is:

Excalibur Electronics, Inc.
13755 SW 119th Ave
Miami, Florida 33186 U.S.A.
Phone: 305.477.8080
Fax: 305.477.9516
www.ExcaliburElectronics.com

Ship the unit carefully packed, preferably in the original carton, and send it prepaid, and adequately insured. Include a letter, detailing the complaint and including your daytime telephone number, inside the shipping carton. If your warranty has expired and you want an estimated fee for service, write to the above address, specifying the model and the problem.

NOTE: Please do not send your unit without first receiving an estimate for servicing from EXCALIBUR ELECTRONICS, INC. Contact us before sending your unit. We cannot store your unit!

Excalibur Electronics, Inc. reserves the right to make technical changes without notice in the interest of progress.

Excalibur Electronics, Inc.
13755 SW 119th Avenue
Miami, Florida 33186
Phone: 305.477.8080
Fax: 305.477.9516
Please Visit Us At:
www.ExcaliburElectronics.com

H638S-WC-CS Master Light 071707

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>